Machine operation

Additional information (including troubleshooting and service) can be found in the individual chapters of the instructions for use.

Sort laundry according to care symbols:

Do not tumble dry

Suitable for tumble drying - at low drying temperature

Suitable for tumble drying

Sort by:

Material thickness: Whenever there is greater load than the dryer can handle, separate laundry according to weight (e.g. dry towels and thin underwear separately).

Type of material: Cotton (linen); synthetic textiles (easy care).

Degree of drying: Cupboard dry, iron dry etc.

Do not tumble dry: Woollens, silk, nylon stockings, delicate embroidery, fabrics with metallic decorations, bulky items such as sleeping bags, etc.

Preparing laundry

Check that all fastenings are closed and that pockets are empty. Please ensure that there are no cigarette lighters in the wash. Turn laundry inside out.

Opening door

Pull the door handle.

Loading dryer

Place laundry loosely in the drum to achieve equal drying throughout. Then close the door.

Selecting programme

Select the drying programme required by turning the programme selector knob (for information, refer to programme table).

Selecting options (if available)

Select the option required by pressing the corresponding button.
The indicator lamp above the relevant button lights up to confirm your selection. A fast blinking led indicates a wrong selection is made (incompatible options). Press the button again to cancel the option.

Starting dryer

The drying programme is started by pressing the **"Start (Pause)"** button ⏯. The relevant indicator lamp lights up.
Changing programme selection: If the programme selected is changed during drying, the dryer stops. The **"Start (Pause)"** indicator lamp ⏯ flashes. To operate the new programme, again press the **"Start (Pause)"** button ⏯.
Interrupting programme: To interrupt a drying cycle, press the **"Start (Pause)"** button ⏯ and open the door. Wait at least 5 minutes, to allow the laundry to cool down, before you unload the dryer. For your safety the drying cycle stops automatically if you open the door. To restart, after door opening, close the door and press the **"Start (Pause)"** button ⏯ again.
Warning: Never stop a tumble dryer before the end of the drying cycle, unless all items are quickly removed and spread out so that the heat is dissipated.

Programme end - unloading dryer

The final part of a tumble dryer cycle occurs without heat (cool down cycle) to ensure that the items are left at a temperature that ensures that the items will not be damaged.

End **End:** Take the laundry out of the dryer. The drying process is complete and the anti-crease phase has been reached (active).

Anti-Crease: If the laundry is not removed at the end of the drying cycle, an automatic anti-crease cycle will operate for maximum 15 min. The drum rotates at regular intervals to prevent the laundry from creasing.

Switching dryer off

Set the programme selector knob to "Off" " ◯ ".

Cleaning the lint filter: Open door, pull lint filter up and out of machine and open it. Brush lint using a soft brush or your fingertips. Push lint filter firmly back into place.

Please note: Only use additives/plastic items specified as dryer safe and rinse items that have been treated with stain remover thoroughly in plenty of water before drying. Never dry rubber objects or objects stained with vegetable oils in the dryer.

Overview of programmes

Programmes / Drying levels — Type of textile			Fabrics	Volume of load kg	Options: Gentle	Rapid Cotton	Buzzer	Anti-crease	Start delay	Approximate drying times (in minutes): Very wet load	Wet load
Cotton	**Ready to wear**	Multi-layered, thick laundry such as: terry towels, dish cloths and dry towels, bed linen, underwear, terry towelling bath robes.	Cotton or linen hot wash / coloured laundry Max. 7 kg	3.0 7.0	X	X	X	X	X	95' 205'	80' 170'
	Cupboard dry *	Similar types of laundry which do not require ironing such as: dry towels, bed linen, underwear, baby clothes, T-shirts, cotton socks.		3.0 7.0	X	X	X	X	X	80' 170'	60' 145'
	Iron dry *	Laundry which requires ironing such as: bed and table linen, dry towels, T-shirts, polo shirts, work clothes.		3.0 7.0	X	X	X	X	X	60' 145'	50' 115'
Mixed fabrics	**Ready to wear**	Laundry with thick, multi-layered areas such as: bed and table linen, track suits, anoraks, blankets.	Synthetic, mixed fibre or cotton easy care (ironing not required) laundry Max. 3.5 kg	1.0 3.5	X	-	X	X	X	30' 85'	25' 65'
	Cupboard dry *	Laundry which does not require ironing such as: shirts, blouses, T-shirts, sportswear.		1.0 3.5	X	-	X	X	X	25' 70'	20' 60'
	Iron dry	Laundry which requires ironing such as: trousers, dresses, skirts, shirts, blouses.		1.0 3.5	X	-	X	X	X	20' 60'	15' 55'
Delicate plus	**Cupboard dry**	Low drying intensity for delicates and items labelled with ⊙, such as: trousers, dresses, shirts, blouses.	Laundry made from synthetic fibres such as polyamide, nylon, polyacrylic, etc. Max. 2.5 kg	2.5	-	-	X	X	X	70'	55'
Airing	**Laundry is aired and refreshed for 30 minutes without heating.**			-	-	-	X	-	X	-	-
Drying times	**Completes drying for min.3-5 full size textiles (suitable for all fabrics).**		10' 20' 30' 40' 60' 90'	-	X	-	X	X	X	10' 20' 30' 40' 60' 90'	

* Test programme in accordance with EN 61121.

How to proceed if ...

...you want to correctly care for and clean your dryer:	**Clean the filter at the end of every cycle.** **Please de-install once a year the air hose and remove the lint inside.**	• Open the door. • Pull the filter upwards. • Brush lint using a soft brush or your fingertips. • Push the filter back into place.
...you want to check the dryer yourself first: (If your machine is not functioning correctly, please check the following points before phoning for the customer service – also refer to relevant chapter in the instructions for use).	**Drying takes too long laundry is not dry enough.**	• Has the correct drying programme been selected? • Was the inserted laundry too wet (washing machine spin speed less than 1000 rpm?) • Is the lint filter dirty (filter indicator light on)? • Is the room temperature too high? • Are the "End" " End " and "Anticrease" " " indicator lamps lighting up? The drying cycle is complete and the laundry can be taken out. • If the drying result does not meet your expectation, select a more dry programme.
	The dryer will not operate (after a power failure, always press the "Start (Pause)" button ⏯).	• Is the plug properly inserted into the mains electricity socket? • Is there a power failure? • Has the fuse blown? • Is the door properly closed? • Has a drying programme been selected? • Has the **"Start (Pause)"** button ⏯ been pressed? • Has the start delay option been selected ? • Is the dryer overloaded? Please remove a part of the load.
	Lint filter indicator lamp on.	• Is the lint filter clean? • Is the vent hose blocked? • Is the outside vent hose adaptor blocked?

AFTER-SALES SERVICE

If the fault is still present once the above checks have been undertaken or should the fault occur for a second time, switch the machine off. Please contact your after-sales service representative (for more information, refer to the warranty manual).

Please have the following details ready when calling your after-sales service representative:

- The nature of the fault.
- The dryer type and model.
- The service code (the number after the word Service on the adhesive rating plate) on the right-hand side when the door is open.

SERVICE 0000 000 00000

Whirlpool Home Appliances

Before using the machine, please also read the instructions for use carefully!

AWZ 880 Quick Reference Guide

GB



Programme selector knob

The drying programme is selected by turning this knob.

"Start (Pause)" button

The drying programme is started by pressing this button. The indicator lamp flashes during the selection phase and lights up during drying.

Indicator lamps

Filter

The indicator lamp lights up when the filter needs cleaning.

Clean the filter at the end of every cycle.

Time remaining display

Depending on the programme selected, once the drying cycle has been started, a default drying time is displayed. The time displayed is corrected by a few minutes depending on the volume, type and dampness of the laundry.

The drying time specified is a calculated value which will be updated during the drying programme.

The flashing lines indicate that the calculation is running. The remaining time will be updated.

Overdry protection

The indicator lamp lights up when a humidity controlled program is selected, to indicate the working protection function. Function is not active in time controlled programmes 10', 20', 30', 40', 60', 90' and "Airing" " ".

Programme sequence



Options

Gentle

Reduces drying intensity (recommended for delicate items).



Rapid Cotton

Shortens drying duration (recommended for thin items of the same size).

Buzzer

Signals/sounds end of drying cycle.

Anticrease

Prevents laundry from creasing up to 12 hours. Buzzer and Anticrease cannot be selected together.

Delayed Start

Delays the start of the drying cycle by 1 to 12 hours. Each time the button is pressed, the start time is delayed by 1 hour.
Then press the **"Start (Pause)"** button to confirm the final selection and to start the dryer. The delayed start indicator lamp flashes and the countdown counts down in 1-hour intervals. The countdown is indicated by the indicator lamp above the button flashing. During the countdown, the drum will turn from time to time to re-distribute the laundry. To cancel or change the previously set time delay, set the programme selector knob to "Off" " " or open the door.

Whirlpool is a registered trademark of Whirlpool USA

5019 307 01454
(Subject to technical modifications)